


Quick Start Guide

BP-206



Packing List

■ Standard Accessories



Printer



Power Adapter



Power Cord



CD




Quick Start Guide



USB Cable




Roll Paper




Serial Cable

■ Optional Accessories




Beam Cover




Wall Hanging Loading

Appearance and components


■ Front View



■ Rear View




■ Open the Top Cover




Paper Loading


1. Press the cover open button to open the printer cover.




2. In the correct direction of the roll paper, install the roll paper.



3. Pull out some roll paper, and close the printer cover.




4. Tear the extra paper in the direction of printer.



Power Supply

1. Make sure the power switch is in "OFF".
2. Connect power adapter to printer.
3. Connect power adapter to power cord.
4. Plug the other side of power cord into the socket nearby.



Interface

